

a.1. Loading the data and plotting the sensor locations




a.2. Time points: [0, 100, ..., 800] Ms.

Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio




a.3. Making the color limit for all the topo plots the same.

Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio (the color limit for all the topoplots is the same)




a.4. I also made a series of topographical plots at the same time points without getting the average of data 20 millisecond before and after the time point.

Time-Averaged Across All Trials (Without averaging from 20 ms before to 20 ms after)




b.1. Finding the peak time of the ERP between 100 and 800 MS and making a topographical plot of the peak.

In the displayed figure, the color scheme indicates the timing of responses, where blue represents the earliest response and red represents the latest. Shades in between denote relative response timings based on their color intensity. Upon examination, electrodes Cpz, Cp2, Cp1, P1, P10, P9 exhibit the earliest response. This trend is also evident in the upper left section of the scalp. Conversely, electrodes like Iz, Fp2, Af8, and F8 show the latest response.




b.2. Below you can find the temporal average visualization for each electrode, presented separately.



c.1. Applying large Laplacian filter and re[eating section a.


By implementing the large Laplacian filter, we significantly enhance the spatial precision of the EEG data. The Laplacian filter operates on the principle of spatial second derivatives, which emphasizes local changes in the signal. As a result, this technique sharpens the topographic representation of the electrical activity on the scalp, allowing for a more detailed and localized observation. When comparing the results from step (c) with those from step (a), it becomes evident that the Laplacianfiltered data provides a clearer distinction between active and nonimproved localization active regions. This can be particularly beneficial in identifying focal brain activities and can aid in the interpretation of the underlying neural sources. Thus, the large Laplacian filter emerges as an essential tool for a more precise spatial analysis of EEG data.

Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio



c.2. Making the color limit for all the topo plots the same.

Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio (the color limit for all the topoplots is the same)



```
from scipy.io import loadmat
import numpy as np
import mne
import matplotlib.pyplot as plt
# 1. Load the .mat file
data = loadmat('sampleEEGdata.mat')
EEG = data['EEG']
eeg data = EEG['data'][0, 0] #eeg data.shape=(64, 640, 99), [channels:64,
time points:640, trials:99]
times = EEG['times'][0, 0][0] #times.shape= (640,)
print('EEG.shape:', EEG.shape) #EEG.shape: (1, 1)
print('eeg data.shape:', eeg data.shape) #EEG.shape: (1, 1)
print('times.shape:', times.shape) #EEG.shape: (1, 1)
microvolt = "uV"
# a.1. Extract Epochs from 0 to 800 ms
# Given a sampling rate of 256 Hz, the time interval between two consecutive
samples is 1/256 = 3.90625 ms. (I consider 4ms for each sample point)
# Thus, 0 ms corresponds to the sample point at index 256,
# and 800 ms corresponds to the sample point at index (800 / 3.90625) =
256+204.8=460.8, which can be rounded to 461.
eeg data epoch= eeg data[:, 256:462, :] # eeg data epoch.shape: (64, 206, 99),
256:462:
#This indexes elements from the 256th to the 461st along the second
dimension(since Python indexing is 0-based and the stop value in a slice is
exclusive).
eeg data epoch 20= eeg data[:, 251:467, :] # eeg data epoch 20.shape:(64,
216, 99), adding the sample point (-20,0) and (800,820) to my epoch.
# print('eeg data epoch.shape:', eeg data epoch.shape,
'eeg data epoch 20.shape', eeg data epoch 20.shape )
# Compute the ERP at each electrode by averaging across all trials
ERP = np.mean(eeg data epoch, axis=2) # shape: (64, 206)
ERP 20 = np.mean(eeg data epoch 20, axis=2) # shape: (64, 216)
# Read the file content
with open('eloc64C2.txt', 'r') as f:
   lines = f.readlines()
# Extract channel names, theta, and radius
channel names = [line.split()[3].replace('.', '') for line in lines[0:]] #
Skip the header
theta = np.array([float(line.split()[1])-90 for line in lines[0:]]) * np.pi /
180.0 # Convert to radians
radius = np.array([float(line.split()[2]) for line in lines[0:]])
# Convert polar to Cartesian
x = radius * np.cos(theta)/5
```

```
y = -radius * np.sin(theta)/5
z = np.zeros like(x) # default z-coordinate for all channels
# Create a montage
ch pos = dict(zip(channel names, zip(x, y, z)))
montage = mne.channels.make dig montage(ch pos, coord frame='head')
info = mne.create info(ch names=channel names, sfreq=256, ch types='eeg')
# Apply the montage to the info
info.set montage(montage)
###############################
# Create an evoked object
# The evoked object is an instance of the EvokedArray class in MNE, which is
useful for visualization and further processing in the MNE ecosystem.
#ERP: It is a 2D numpy array that contains the event-related potential
values. This is a simple numeric representation with dimensions corresponding
to channels and time points.
#evoked: It is an object of type EvokedArray that wraps around the ERP numpy
array. It integrates the numeric ERP data with metadata (info)
#and provides various methods and attributes for easier visualization and
analysis of the data in the context of the MNE-Python library.
evoked = mne.EvokedArray(ERP, info)
evoked 20 = mne.EvokedArray(ERP 20, info)
# a.2. Plot the topographical map
# The evoked.plot topomap() function from the MNE-Python library is used to
plot topographical maps of EEG data,
# giving a spatial representation of voltage (or other measures) across the
scalp at specific points in time.
evoked.plot topomap(times=np.linspace(0, .8, 9), nrows=3, ncols=3, size=1,
cmap='jet', time unit='s', show=False)
plt.suptitle("Time-Averaged Across All Trials \n (Without averaging from 20
ms before to 20 ms after)", y=1.05)
plt.show()
```

#########

Plot the sensor locations

When you're plotting EEG channels with plot_sensors, MNE sometimes creates two plots: one for a top-down view and another for a side view,

especially when 3D channel locations (with both horizontal and vertical coordinates) are present.

You can suppress the side view by setting the proj argument to True: evoked.plot sensors(kind='topomap', show names=True, ch type='eeg')

a. Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio plt.close('all')

center_times = np.linspace(0, .8, 9) # 0ms, 100ms, ..., 800ms
fig, axs = plt.subplots(3, 3, figsize=(10,8))


fig.suptitle("Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio", fontsize=12, y=1.05)


AVE ERP=[]

for idx, center_time in enumerate(center_times):


```
start time = center time - 0.020
    end time = center time + 0.020
    avg data = evoked 20.copy().crop(tmin=start time,
tmax=end time).data.mean(axis=1)
   AVE ERP.append(avg data)
   ax = axs[idx // 3, idx % 3]
   im, = mne.viz.plot topomap(avg data, evoked 20.info, cmap='jet',
axes=ax, show=False)
    fig.colorbar(im, ax=ax, format='%3.1f', orientation='vertical',
label='Voltage (µV)')
    ax.set title(f"Center: {center time*1000:.0f} ms\nMean:
({start time*1000:.0f} ms to {end time*1000:.0f} ms)")
plt.tight layout()
plt.show()
AVE ERP np=np.array(AVE ERP)
# print('AVE ERP np.shape', AVE ERP np.shape) #(9,64)
# Making the color limit for all the topoplots the same
plt.close('all')
center times = np.linspace(0, .8, 9) # 0ms, 100ms, ..., 800ms
fig, axs = plt.subplots(3, 3, figsize=(10, 8))
fig.suptitle("Time-Averaged Topographical Maps for Enhanced Signal-to-Noise
Ratio\n (the color limit for all the topoplots is the same)", fontsize=12,
y=1.05)
global vmin, global vmax = AVE ERP np.min(), AVE ERP np.max()
for idx, center time in enumerate(center times):
    start time = center time - 0.020
    end time = center time + 0.020
    ax = axs[idx // 3, idx % 3]
    im, = mne.viz.plot topomap(AVE ERP np[idx, :], evoked 20.info,
cmap='jet', axes=ax, show=False)
    # Adjust the color limits to reflect the global max and min
   im.set clim(global vmin, global vmax)
    fig.colorbar(im, ax=ax, format='%3.1f', orientation='vertical',
label='Voltage (\mu V)')
    ax.set title(f"Center: {center time*1000:.0f} ms\nMean:
({start time*1000:.0f} ms to {end time*1000:.0f} ms)")
plt.tight layout()
plt.show()
# print('AVE ERP np.shape', AVE ERP np.shape) # (9, 64)
EEG.shape: (1, 1)
eeg data.shape: (64, 640, 99)
times.shape: (640,)
```

Time-Averaged Across All Trials (Without averaging from 20 ms before to 20 ms after)







● lz




Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio (the color limit for all the topoplots is the same)



```
# Show colorbar
plt.colorbar(im, ax=ax, label='Peak Time (ms)')
plt.title("Peak Time of the ERP")
plt.show()
```




###########



```
# C.
with open('eloc64C2.txt', 'r') as f l:
    lines l = f l.readlines()
channel names 1 = [line l.split()[3].replace('.', '') for line l in
lines 1[0:]]
theta l = np.array([float(line l.split()[1]) for line l in lines 1[0:]]) *
np.pi / 180.0
radius 1 = np.array([float(line l.split()[2]) for line 1 in lines 1[0:]])
x l = radius l * np.cos(theta l)
y l = radius l * np.sin(theta l)
z l = np.zeros like(x l)
radius range = [0.18, 0.28]
laplacian data = np.zeros like(ERP 20)
for i in range(64):
    distances = np.sqrt((x 1 - x 1[i]) ** 2 + (y 1 - y 1[i]) ** 2)
    surrounding indices = np.where((distances > radius range[0]) & (distances
< radius range[1]))[0]</pre>
    if len(surrounding indices) > 0:
        weights = 1 / distances[surrounding indices]
        weights = weights / np.sum(weights) # Normalize weights
    else:
        weights = np.array([])
    weights = weights[:, np.newaxis]
    if len(weights) > 0:
        laplacian data[i, :] = ERP 20[i, :] - np.sum(weights *
ERP 20[surrounding indices, :], axis=0)
        laplacian data[i, :] = ERP 20[i, :]
laplacian raw = evoked 20.copy()
laplacian raw. data = laplacian data
plt.close('all')
center times = np.linspace(0, .8, 9)
fig, axs = plt.subplots(3, 3, figsize=(10,8))
fig.suptitle("Time-Averaged Topographical Maps for Enhanced Signal-to-Noise
Ratio", fontsize=12, y=1.03)
AVE ERP l=[]
for idx, center time in enumerate(center times):
    start time = center time - 0.020
    end time = center time + 0.020
    avg data l = laplacian raw.copy().crop(tmin=start time,
tmax=end time).data.mean(axis=1)
    AVE ERP l.append(avg data)
    ax = axs[idx // 3, idx % 3]
    im, _ = mne.viz.plot_topomap(avg_data_1, laplacian_raw.info, cmap='jet',
axes=ax, show=False)
    fig.colorbar(im, ax=ax, format='%3.1f', orientation='vertical',
label='Voltage (µV)')
    ax.set title(f"Center: {center time*1000:.0f} ms\nMean:
({start time*1000:.0f} ms to {end time*1000:.0f} ms)")
plt.tight layout()
plt.show()
```

```
AVE ERP np l=np.array(AVE ERP)
plt.close('all')
center times = np.linspace(0, .8, 9)
fig, axs = plt.subplots(3, 3, figsize=(10, 8))
fig.suptitle("Time-Averaged Topographical Maps for Enhanced Signal-to-Noise
Ratio\n (the color limit for all the topoplots is the same)", fontsize=12,
y=1.03)
global vmin, global vmax = AVE ERP np l.min(), AVE ERP np l.max()
for idx, center time in enumerate(center times):
    start time = center time - 0.020
    end time = center time + 0.020
    ax = axs[idx // 3, idx % 3]
    im, = mne.viz.plot topomap(AVE ERP np l[idx, :], laplacian raw.info,
cmap='jet', axes=ax, show=False)
    im.set clim(global vmin, global vmax)
    fig.colorbar(im, ax=ax, format='%3.1f', orientation='vertical',
label='Voltage (µV)')
    ax.set title(f"Center: {center time*1000:.0f} ms\nMean:
({start time*1000:.0f} ms to {end time*1000:.0f} ms)")
plt.tight layout()
plt.show()
C:\Users\tnlab\AppData\Local\Temp\ipykernel 16184\2574989804.py:37: RuntimeWa
rning: tmin is not in time interval. tmin is set to <class 'mne.evoked.Evoked
Array'>.tmin (0 s)
  avg data 1 = laplacian raw.copy().crop(tmin=start time, tmax=end time).data
.mean(axis=1)
```



Time-Averaged Topographical Maps for Enhanced Signal-to-Noise Ratio (the color limit for all the topoplots is the same)

